

Knowing how to operate your Thermomix™ safely is just as important as knowing the favourite dishes of your loved ones. We have gathered all essential safety rules in this compilation called Thermomix™ Basics: Look up all the basics, learn how to use the Thermomix™ safely and discover everything you need to know about the accessories!

Accessories



USE GREEN SEALING RING:

Only use your Thermomix™ TM31 with the green sealing ring in the lid of the mixing bowl. If you don't have a green sealing ring, you can order one through your local customer service.



LOCK PROPERLY:

Make sure that all parts (including the mixing knife, mixing knife sealing ring, mixing bowl base, mixing bowl, mixing bowl lid, lid sealing ring, measuring cup and Varoma) are properly locked and correctly positioned as intended.



OPEN CAREFULLY:

Open the mixing bowl lid with care – never try to force it open. For TM31: Only open the lid when the processed food has stopped moving and the speed selector is pointing to “lid open” position.



AVOID FAKE COPIES:

Only use original parts or accessories provided with and designed for your Thermomix™.